



MODERN
STAINLESS
HARDWARE

INSTALLATION INSTRUCTIONS

1. Measure the center to center distance of the two screw holes on your house number, then drill two holes into your mounting surface.
2. Insert the two plastic anchors into the two holes.
3. Screw the two posts into the back of your house number.
4. Using a soft cloth or sponge to protect the surface of your house number, gently tap the house number posts into the plastic anchors with a rubber mallet or hammer.

